

October, 1987

Manual 6055-3

✓ Supersedes Manual 6055-3
Dated March, 1986

Instruction & Maintenance Manual

Vacuum Circuit Breaker Type VAD-2 Series 2



SQUARE D COMPANY

VACUUM CIRCUIT BREAKER TYPE VAD-2
SERIES 2

CONTENTS

Description	Page
STATEMENT PAGE	3
1.0 INTRODUCTION	4
1.1 Receiving	4
1.2 Handling	4
1.3 Storage	4
2.0 INITIAL BREAKER PREPARATION	5
3.0 VACUUM CIRCUIT BREAKER - DESCRIPTION	5
3.1 Vacuum Interrupters	5
3.2 Primary Disconnects	5
3.3 Operating Mechanism	5
3.4 Control Circuitry	5
3.5 Indicators	7
3.6 Manual Charging	7
3.7 Slow Closing Feature	7
3.8 Drawout Operation	8
3.9 Test Position Operation	9
4.0 OPERATING MECHANISM - DESCRIPTION OF OPERATION	9
4.1 Drive Spring Charging	9
4.2 Closing Operation	10
4.3 Opening Operation	10
4.4 Spring Discharge Interlocks	11
5.0 ADJUSTMENTS	11
5.1 Trip Open Eccentric	12
5.2 Toggle Bearing Clearance	12
5.3 Charging Motor Limit Switch	12
5.4 Adjustments Affecting the Vacuum Interrupters	12
6.0 MAINTENANCE	13
6.1 Vacuum Interrupters	13
6.2 Insulating Surfaces	13
6.3 Mechanism	13
6.4 Lubrication	14
6.5 Electrical	15
6.6 Overhaul	15
7.0 RENEWAL PARTS	15
7.1 Minimum Requirements	15
7.2 Ordering Instructions	15
8.0 CONTROL SCHEMATIC DIAGRAMS	(16—17)



**VACUUM CIRCUIT BREAKER TYPE VAD-2
SERIES 2**

CLASS
6055

**STATEMENT OF USE OF SURGE PROTECTION
FOR VACARC CIRCUIT BREAKERS**

VACARC® medium voltage vacuum circuit breakers are designed and tested in accordance with ANSI C37.04, .06, and .09. Used in conjunction with switchgear designed and tested to ANSI C37.20, circuit breakers can be applied as general purpose devices.

Users may elect to install VACARC circuit breakers over a wide range of applications and system parameters. Several IEEE publications are available to provide guidance to the use for industry practices (IEEE Color Book Series).

Special attention is suggested by the user when considering old or aging distribution systems. Distribution systems can be exposed to lightning or switching surges. Older or aging systems may be more susceptible to damage due to system insulation aging or being built to older standards.

Recognizing this, users are encouraged to consider adding metal oxide surge arrestors to the circuitry on the load side of the terminals of VACARC breakers used in retro-fit applications. Placement should be in the switchgear or at the equipment being protected but not on the circuit breaker.

Metal oxide arrestors limit the magnitude of prospective overvoltages but do not affect the rate of rise (di/dt) of surge transients. Surge capacitors can be considered for this additional protection.






Figure 1

1.0 INTRODUCTION

This manual provides installation, operation and maintenance instructions for all models of this series of horizontal drawout vacuum circuit breakers. Available in all standard ratings and meeting or exceeding all applicable industry standards, these breakers provide three-cycle interruption, long switching life and ease of operation and maintenance.

1.1 Receiving

Upon receipt, by the customer, the entire breaker should be inspected for damage that may have occurred in transit. All items should be checked against the packing list provided. The transportation company and the manufacturer should be notified immediately of damages or shortages.

1.2 Handling

Use care when uncrating and handling the breaker. NEVER USE THE PRIMARY DISCONNECTS AS HANDLES. Roll and maneuver the breaker by grasping the handle holes at the

top of the front mechanism cover (Figure 1, 1). When using a fork lift or hoist, lift the breaker by the strong points of the frame to prevent damage.

1.3 Storage

If the breaker must be stored before it is put into operation, keeping it in a place that is clean, dry and free of corrosive elements and mechanical abuse is absolutely necessary. Coat all bare metal surfaces with grease to prevent rusting. See Lubrication Chart, page 14.

The manufacturer recommends that the breaker be put in its permanent location as soon as possible. If the breaker is to function in outdoor switchgear, install it only when power is available and heaters are operating.

Breakers that must be stored for prolonged periods should be inspected regularly for rusting and overall condition. Lubrication should be performed when necessary.

2.0 INITIAL BREAKER PREPARATION

The following describes the steps that are necessary to prepare the breaker for installation into its enclosure:

- 1) Examine the entire breaker.
- 2) Use a clean, dry cloth to remove dirt and moisture that may have collected on the outside of the vacuum interrupters (Figure 8, 5) and all insulating parts.
- 3) Cycle the breaker manually several times and check for proper operation. This is accomplished by using the handle supplied with the breaker to move the manual charging arm (Figure 1, 7) up and down until the drive springs (Figure 5, 1) are fully charged. The drive springs are fully charged when the charge-discharge indicator (Figure 1, 2) reads "charged" and the manual charging arm can no longer be raised.
- 4) Electrically operate the breaker several times and check for proper operation.
- 5) To assure that damage has not occurred during shipment, perform a hi-pot test across the open contacts of each vacuum interrupter. Then, with the breaker in the closed position, perform a phase to ground and phase to phase hi-pot test for each pole.

Gradually raise the voltage to the proper level. The hi-pot test voltage should be 19kV AC or DC for a 4.16kV class breaker of 27kV AC or DC for a 7.2kV or 13.8kV class breaker. The breaker should sustain this potential for 1 minute. Do not attempt to compare the condition of one vacuum interrupter with another, nor to correlate the condition of any interrupter to low values of leakage current. There is no significant correlation. Observe the following instructions when performing the hi-pot test:
 - a. Do not exceed the above voltages.
 - b. All persons should stay at least 6 feet away from the breaker under test.
 - c. Perform tests only when all insulating parts are installed.
 - d. Discharge to ground the primary disconnects (Figure 7, 1) and vacuum interrupter mid-band ring (Figure 8, 6) before handling. These areas can retain a static charge after a hi-pot test.
- 6) Insert the breaker into its enclosure by following any applicable directions provided by the enclosure manufac-

turer. See section 3.8 for a description of the drawout operation of the breaker itself.

- 7) With the main power off, cycle the breaker several times and check for proper operation.
- 8) The breaker is now ready for normal operation.

3.0 VACUUM CIRCUIT BREAKER - DESCRIPTION

3.1 Vacuum Interrupters

Interruption in the vacuum circuit breaker is performed by the vacuum interrupters (Figure 8, 5) mounted vertically within the breaker frame. Consisting of a pair of butt contacts, one moveable and one fixed, hermetically sealed in a high vacuum these interrupters require only a short contact gap for circuit interruption. The resulting high operating speed allows the entire operating sequence, from fault to clear, to be consistently performed in three cycles or less.

3.2 Primary Disconnects

The primary connection to the associated switchgear is made through the six primary disconnects (Figure 7, 1) mounted horizontally at the rear of the breaker. Take care to insure that the primary disconnects do not receive rough treatment. **NEVER USE THE PRIMARY DISCONNECTS AS HANDLES WHEN MANEUVERING THE BREAKER.**

3.3 Operating Mechanism

The operating mechanism is of the stored energy type employing charged springs to perform breaker opening and closing functions. The operating mechanism contains all necessary controls and interlocks. It is mounted at the front of the breaker so that it can be easily accessed for inspection and servicing. Opening and closing can be performed electrically or manually.

3.4 Control Circuitry

A typical schematic diagram for the control circuitry of the circuit breaker is presented in Figure 9. The following describes the operation of the various components of the control circuitry.

3.4.1 AUXILIARY SWITCH

The auxiliary switch (Figure 3, 5) is a multi-stage switch used to operate those circuits which are dependent upon the position of the breaker contacts. The schematic diagram of Figure 9 indicates how each of the auxiliary switch stages are interconnected with the breaker circuitry. The function of each stage is discussed below.



- a. Two a-type auxiliary contacts are connected in series with the trip coil (TC). (NOTE: For 250VDC control three a-type contacts are employed.) Since these stages are open when the breaker is in the open position, the auxiliary contacts prevent the trip coil from being energized when the breaker is in the open position.
- b. The b-type contact, connected in series with the closing coil, disables the closing coil when the breaker contacts are in the closed position.
- c. For user convenience in indicating the position (opened or closed) of the breaker contacts, Figure 9 indicates how a green light (contacts open) and a red light (contacts closed) can be connected to the breaker control circuitry.
- d. Typically two b-type contacts and two a-type contacts are connected to the secondary disconnect, as shown in Figure 9, for optional use. (Other variations can occur depending upon latch check switch and other optional requirements. Consult the cubicle manufacturer's diagrams where necessary.)

3.4.2 CHARGING MOTOR LIMIT SWITCH

The charging motor limit switch (Figure 2, 4) energizes the motor relay (Figure 3, 4) when a drive spring charging operation is required and de-energizes the motor relay when the drive springs (Figure 5, 1) reach the fully charged position. As shown in the schematic diagram of Figure 9, the charging motor limit switch (LS) is connected in the normally open position. Whenever the drive springs are not in the fully charged position, the charging motor limit switch cam (Figure 2, 5) actuates the charging motor limit switch. The cam allows the switch to assume its normally open position once the drive springs are fully charged.

3.4.3 MOTOR RELAY

When energized by the closing of the spring charging motor limit switch (LS), the motor relay (MR) energizes the spring charging motor (M) through a pair of normally open contacts and disables the closing coil (X) through a pair of normally closed contacts.




Figure 2

3.4.4 ANTI-PUMP RELAY

The anti-pump relay insures that, should the control switch (CS/C), which energizes the closing coil, be continuously maintained in the closed position, the springs will not be continuously charged and discharged. The anti-pump relay performs this function by allowing the closing coil to be energized only if the control switch (CS/C) is closed after the drive springs have reached the fully charged position and the motor relay (MR) has been de-energized.

The anti-pump relay will be energized if the control switch (CS) is closed and the motor relay (MR) is energized. If the control switch is held continuously, the anti-pump relay will be latched in the energized position after the motor relay is de-energized by a pair of its own normally open contacts. When the anti-pump relay is energized, a pair of its normally closed contacts, in series with the closing coil, insure that the closing coil cannot be energized by the control switch. The closing coil cannot be energized unless the control switch is first opened (de-energizing the anti-pump relay), then closed again.

3.4.5 LATCH CHECK SWITCH (OPTIONAL)

When specified a latch check switch (LC) can be supplied. (Normally a latch check switch is specified only when the breaker is to be used for instantaneous reclosing.) The contacts of the latch check switch are connected in series with the closing coil (X). The latch check switch is actuated by the trip opening cam (Figure 6, 10) only when the cam is in its normal position as shown in Figure 6. Thus, the closing circuit cannot be energized until the trip opening cam has fully returned to its normal position.

3.4.6 PERMISSIVE TRIP DEVICE (OPTIONAL)

When specified a permissive trip device (69) can be supplied. (This is a safety feature that is sometimes desired by users who employ remote control or automatic reclosing schemes.) The permissive trip device is a toggle switch whose contacts are connected in series with the closing coil (X). These contacts are normally maintained in the closed position. A manual trip operation will mechanically cause the contacts to open. To once again complete the electrical closing circuit the permissive trip device must be manually reset. It is accessed via the optional cutout in the front mechanism cover that is labeled "Emergency/Manual Trip Reset."

3.5 Indicators

Two indicators are provided on the operating mechanism. The open-close indicator (Figure 1, 6) designates the position of the vacuum interrupter contacts. The charge-discharge indicator (Figure 1, 2) displays the state (charged or discharged) of the drive springs (Figure 5, 1).

3.6 Manual Charging

The drive springs (Figure 5, 1) can be manually charged by using the handle supplied with the breaker to move the manual charging arm (Figure 1, 7) up and down until the drive springs are fully charged. The drive springs are fully charged when the charge-discharge indicator (Figure 1, 2) reads charged and the manual charging arm can no longer be raised.

3.7 Slow Closing Feature

For some maintenance functions it may be desirable to manually slow close the circuit breaker. For such purposes, the operating mechanism provides a built-in slow closing feature.




Figure 3



Manual slow closing is accomplished as follows:

- a. With the breaker in the open position and the drive springs charged, insert the drive spring blocking pins (supplied with the breaker) into the hole at the upper end of each drive spring center shaft. (Removal of the front mechanism cover is required.)
- b. Discharge the drive springs.
- c. Using the manual charging handle, slowly charge the drive springs as described in section 3.6. The circuit breaker will begin to slow close.

3.8 Drawout Operation

IMPORTANT: THE RACKING MECHANISM IS INTERLOCKED WITH THE BREAKER OPERATING MECHANISM SUCH THAT THE RACKING MECHANISM WILL NOT OPERATE UNLESS THE BREAKER IS IN THE OPEN POSITION. NEVER FORCE THE RACKING MECHANISM. ALWAYS PLACE THE BREAKER INTO THE OPEN POSITION BEFORE ATTEMPTING TO RACK THE BREAKER IN OR OUT.

RACKING IN PROCEDURE

- 1) Check that the breaker racking arms (Figure 1, 3) are in the "drawout position" before inserting the breaker into the cell. In the drawout position the racking arms are extended horizontally towards the rear of the breaker and are resting on their eccentric stops.

- 2) If required, move the racking arms to the drawout position by:

- a. Place the breaker into the open position.
- b. Insert the racking handle into the racking shaft (Figure 1, 9).
- c. Rotate the racking handle counterclockwise until the racking mechanism comes to a stop. Do not over torque.

- 3) Insert the breaker into the cell until the rollers on the racking arms come into contact with the slots in the sides of the cell.

- 4) Rotate the racking handle clockwise until the racking mechanism stops. Do not over torque.

RACKING OUT PROCEDURE

- 1) Place the breaker into the open position.
- 2) Insert the racking handle into the racking shaft (Figure 1, 9).
- 3) Rotate the racking handle counterclockwise until the racking mechanism stops. Do not over torque.
- 4) Lift the footpedal latch at the lower left side of the breaker and roll the breaker out of the cell.




Figure 4

VACUUM CIRCUIT BREAKER TYPE VAD-2 SERIES 2

CLASS
6055

3.9 Test Position Operation

The secondary disconnect (Figure 7, 2) is mounted on a retractable slide so that it can be connected to the control circuit of the cell while the cell shutters are down and the primary connections have not been made. This provides a convenient and safe method for electrically testing the operation of the breaker mechanism and control circuit. Test position operation is achieved by:

- 1) Insert the breaker into the test position of the cell by following steps 1 through 3 of the "Racking In Procedure" outlined in Section 3.8. (Do not rack the breaker into the cell.)
- 2) Pull the secondary slide handle (Figure 1, 10) out of its retaining clip and rotate it out so that it is protruding straight out from the breaker.
- 3) Lift slightly on the secondary slide handle and push it into the breaker until connection is made.
- 4) The control circuit of the breaker is now connected with that of the cell.
- 5) The secondary disconnect may be retracted by reversing the above procedure.

4.0 OPERATING MECHANISM - DESCRIPTION OF OPERATION

The following is a description of the operation of the operating mechanism. This manual will refer to the operating mechanism as the front of the breaker. The terms left and right will be used as if facing the operating mechanism. The terms clockwise and counterclockwise will be used as if facing the left side of the breaker.

4.1 Drive Spring Charging

Assume that the interrupter contacts are in the open position and that the drive springs (Figure 5, 1) and the return springs (Figure 2, 1) are discharged. When power is supplied to the breaker control circuitry (Figure 9), the charging motor (Figure 5, 4) is energized. The motor eccentric (Figure 4, 6), mounted on the charging motor shaft, drives the ratchet arm assembly (Figure 4, 7) backward and forward. With each forward stroke of the ratchet arm, the spring loaded drive pawl (Figure 4, 5), mounted on the ratchet arm, engages a tooth on the gear (Figure 4, 1) and advances the gear a few degrees counterclockwise. The holding pawl (Figure 4, 2) holds the gear in position while the drive pawl makes its reverse stroke to engage another tooth. The gear is free to rotate on the gear shaft (Figure 4, 3). As the gear is advanced, the drive block (Figure 4, 8), mounted on the outside face of the gear, engages the gear on the drive hub (Figure 4, 4) and rotates the drive hub. A roll pin connects the drive hub to the gear shaft (Figure 4, 3) and drive lever (Figure 5, 8) assembly. The gear shaft and drive lever assembly thus rotates with the drive hub.

As the drive lever rotates, the lifting roller (Figure 5, 6) on the drive lever contacts the lift arm (Figure 5, 2) on the drive shaft (Figure 4, 10) and pushes the lift arm up rotating the drive shaft counterclockwise. The counterclockwise drive shaft rotation compresses the drive springs until the spring load against the drive lever passes top dead center and attempts to discharge. At this point, the drive lever rotates a few degrees until the trip closing roller (Figure 5, 9) on the drive lever can rotate no further and the drive springs are held in this charged position until a closing operation is initiated.

When the drive springs reach the fully charged position, the charging motor limit switch cam (Figure 2, 5) allows the charging motor limit switch (Figure 2, 4) to open de-energizing the charging motor. Simultaneously, the pawl lift slide (Figure 4, 9) is pushed forward by the cam lobe on the drive hub so that the drive pawl rides on the pawl lift slide and does not engage the gear. This arrangement allows the charging motor and ratchet assembly to coast smoothly to a stop.



4.2 Closing Operation

Once the drive springs (Figure 5, 1) have been charged, the breaker can be closed by lifting the close lever (Figure 1, 5) or by energizing the closing coil (Figure 2, 3). Either method disengages the trip closing cam (Figure 5, 7) from the trip closing roller (Figure 5, 9) and allows the drive springs to discharge. The discharging drive springs rotate the drive shaft (Figure 4, 10) clockwise. The clockwise rotation of the drive shaft gives the drive spring bearing (Figure 6, 3) a downward motion. The drive spring bearing engages the tog toggle cam (Figure 6, 1) rotating the front of the toggle cam up and the rear of the toggle cam down under the catch (Figure 6, 2). The front of the toggle cam is connected to the main shaft (Figure 2, 7) by the drive linkage (Figure 6, 5). The upward motion of the front of the toggle cam thus rotates the main shaft counterclockwise and compresses the return springs (Figure 2, 1).

The drive connecting links (Figure 3, 3) transform the rotary motion of the main shaft into a linear motion which closes the vacuum interrupter contacts. The trip opening cam (Figure 6, 10) forces the entire toggle assembly (Figure 6) to remain latched in this position.

When the drive springs discharge, rotating the drive shaft in a counterclockwise direction, the descending lift arm rotates the drive lever such that the drive lever completes the remaining

360 degrees of rotation to its initial position where it can once again perform a drive spring charging operation. The gear shaft and drive hub rotate with the drive lever. The drive hub rotates out of contact with the drive block. Since the gear (Figure 4, 1) rotates freely on the gear shaft, the gear remains stationary. The rotation of the drive hub is such that the pawl lift slide (Figure 4, 9) follows the cammed surface of the drive hub until the pawl lift slide moves back below the gear teeth permitting the drive pawl (Figure 4, 5) to engage the gear. The charging motor limit switch cam (Figure 2, 5) rotates with the gear shaft and closes the charging motor limit switch (Figure 2, 4) energizing the charging motor (Figure 5, 4) which once again charges the drive springs.

4.3 Opening Operation

With the return springs (Figure 2, 1) charged, the operating mechanism is now ready to perform an opening operation. If the open lever (Figure 1, 4) is lifted or if the opening coil (Figure 2, 2) is energized, the trip opening cam (Figure 6, 10) will be rotated clockwise out from under the toggle bearing (Figure 6, 9). The force of the charged return springs pushing down on the front of the toggle cam (Figure 6, 1) will cause toggle sub-assembly (Figure 6, 8) to rotate clockwise. When




Figure 5

the rear of the toggle cam clears the catch (Figure 6, 2) the return springs will completely discharge, rotating the main shaft (Figure 2, 7) and the toggle cam clockwise. The clockwise rotation of the main shaft is transformed to a linear motion by the drive connecting links (Figure 3, 3). The drive connecting links are connected to the vacuum interrupters (Figure 8, 5), and their motion opens the vacuum interrupter contacts.

4.4 Spring Discharge Interlocks

The spring discharge interlocks (Figure 5, 5) are located directly below the opening and closing coils (Figure 2, 2 & 3). Three cams, located on the floor of the skeleton cell, engage the spring discharge interlocks in such a manner that the primary disconnects (Figure 7, 1) cannot be engaged or disengaged with the interrupter contacts in the closed position and all springs are automatically discharged whenever a circuit breaker is inserted into or removed from its cell.




Figure 6

5.0 ADJUSTMENTS

All adjustments are factory set and need not be checked when placing a new breaker into operation.

During periodic inspections and when a breaker part is repaired or replaced, the following adjustments should be checked. To perform these adjustments, first remove the breaker from its cubicle, and then remove the front mechanism cover (Figure 1, 1).

CAUTION

WHENEVER AN ADJUSTMENT IS TO BE CHECKED OR PERFORMED WITH THE DRIVE SPRINGS IN THE CHARGED POSITION, IT IS ABSOLUTELY NECESSARY TO BLOCK THE DRIVE SPRINGS BY PLACING THE BLOCKING PINS IN THE HOLES AT THE UPPER END OF THE DRIVE SPRING CENTER SHAFTS. (THE BLOCKING PINS ARE SUPPLIED IN THE ENVELOPE CONTAINING THE INSTRUCTION MANUAL).




Figure 7



5.1 Trip Open Eccentric

With the breaker in the open position and the drive springs charged, the vertical free movement in the opening coil plunger (Figure 2, 2), before engaging the trip open arm (Figure 6, 6), should be $1/8" \pm 1/16"$. Rotate the trip open eccentric (Figure 6, 7) to achieve the proper gap. (If a latch check switch is supplied, this adjustment is not required.)

5.2 Toggle Bearing Clearance

With the breaker in the open position and drive springs (Figure 5, 1) charged, the clearance between the toggle bearing (Figure 6, 9) and the trip opening cam (Figure 6, 10) should be $1/32" + 1/32" - 0"$. If adjustment is necessary, the toggle sub-assembly retainer nut (Figure 6, 11) should be adjusted clockwise to increase clearance, counterclockwise to decrease clearance.

5.3 Charging Motor Limit Switch

Actuated by the charging motor limit switch cam (Figure 2, 5), the charging motor limit switch (Figure 2, 4) serves to energize the charging motor (Figure 5, 4) during a drive spring charging operation and de-energize the charging motor when the drive springs (Figure 5, 1) reach the fully charged position. The

charging motor limit switch is properly adjusted if its contacts are open when the drive springs are in the fully charged position and closed when the drive springs are discharged. The position of the charging motor limit switch contacts can be determined by using a continuity tester. If adjustment is necessary, loosen the two screws which hold the charging motor limit switch in place and move the switch up or down as required. Tighten the two screws.

5.4 Adjustments Affecting the Vacuum Interrupters

The following adjustments need to be made only when a vacuum interrupter is replaced. These adjustments are listed in the order in which they should be performed.

5.4.1 DRIVE LINKAGE *

Distance "A" (Figure 6) for the drive linkage should be $1-5/8" \pm 1/16"$ for circuit breakers with a maximum interrupting rating of 36KA and below. For breakers with a maximum interrupting rating above 36KA, distance "A" should be $19/16" \pm 1/32"$. If adjustment is performed, be certain to tighten the jam nuts when completed.

* NOTE: BREAKERS MANUFACTURED AFTER AUGUST, 1987, MAY NOT EMPLOY ADJUSTABLE DRIVE LINKAGE.

5.4.2 SPRING OVERTRAVEL

When the breaker is in the closed position with the drive springs charged, the spring overtravel (Distance "E", Figure 11) for a new vacuum interrupter assembly should be $3/16" + 1/16" - 1/32"$. Adjustment is performed as follows:

When the breaker is in the closed position with the drive springs charged, check the spring overtravel. If adjustment is necessary, remove the nut (Figure 11, 6) at the end of the drive connecting link. Insert the T-handle adjustment tool #T-1 into the slots in the end of the erosion indicator (Figure 11, 1) and turn the erosion indicator clockwise to shorten or counterclockwise to lengthen the overtravel. **THIS ADJUSTMENT IS FACTORY SET AND SHOULD ONLY BE PERFORMED WHEN INSTALLING A NEW VACUUM INTERRUPTER AS DIMENSION "E" PROVIDES AN INDICATION OF CONTACT EROSION (SEE SECTION 6.1a).** NOTE: Special tool #T-1 can be ordered from the factory.




Figure 8



5.4.3 PRIMARY CONTACT GAP

With the breaker in the open position, the primary contact gap should be 0.500" to 0.625" for breakers rated at maximum interrupting capabilities of 23KA and below or 0.450" to 0.530" for breakers rated at 36KA maximum interrupting capability and above or any breaker rated 3000 amperes continuous current. To determine the primary contact gap, measure distance "D" (Figure 8) with the breaker in the open position, then with the breaker in the closed position. The difference between these two measurements is the primary contact gap.

To adjust the primary contact gap, use the return spring stops (Figure 10, 7). Turn the stops clockwise (viewed from above) to decrease the primary contact gap and counterclockwise to increase the primary contact gap. It should be noted that both stops must be adjusted simultaneously and equally. The return spring stops can be turned easily if the locking nuts are loosened and the breaker is in the closed position. Exercise caution since the return springs (Figure 2, 1) are in the charged position. After performing the adjustment, tighten the locking nuts against the stops. Open and close the breaker, then re-measure the primary contact gap. Repeat the procedure until the correct primary contact gap is obtained. (To facilitate this adjustment after return spring replacement has been performed, the initial setting distance "C" (Figure 10) should be approximately 9-1/8" when the breaker is in the open position).

5.4.4 RETURN SPRING PRE-LOADING SETTING

The return spring pre-load setting is determined by distance "B" shown in Figure 10. This adjustment is factory set to provide the correct contact velocities and should not be changed. If disassembly is ever required, note this setting and readjust to the same distance upon reassembly. To adjust distance "B", turn the adjustable retainer (Figure 10, 2) clockwise (viewed from above) to increase distance "B" and counterclockwise to decrease distance "B".

5.4.5 SHOCK ABSORBER

All shock absorber adjustments and settings have been made at the factory. No adjustments should be necessary. If, however, they are required, consult the factory.

5.4.6 CONTACT COMPRESSION

Once the above adjustments have been performed, cycle the breaker open and closed 25 times to compress the contacts of the new vacuum interrupter(s) which has been installed. After cycling the breaker, remeasure adjustments 5.4.2, 5.4.3 and 5.4.4. Perform these three adjustments again if required.

6.0 MAINTENANCE

For safety, always remove the breaker from its cubicle and discharge or block the drive springs (Figure 5, 1) and the return springs (Figure 2, 1) before performing any maintenance or repair work.

Because of the wide variations in operating uses and environments, each operating company should develop a maintenance schedule, based on operating experience, which will provide assurance of proper breaker condition. Until such a schedule is determined, it is recommended that breakers be inspected after one year or every 3000 operations, whichever occurs first. It is also recommended that breakers be inspected after severe fault operations and notation of any contact erosion be recorded (See 6.1 a).

6.1 Vacuum Interrupters

To assure reliable interruption, perform the following two checks:

- a. Contact Erosion: Any contact erosion will result in a reduction of the spring overtravel. (See Section 5.4.2). Contact erosion can therefore be determined by closing the breaker and measuring the spring overtravel. The difference between this measurement and the original spring overtravel setting at the time the interrupter was first put into service represents contact erosion. The factory setting for spring overtravel is $3/16" + 1/16" - 1/32"$. When the spring overtravel has been reduced to less than $1/16"$ the vacuum interrupter must be replaced.
- b. Hi-pot Test: Hi-pot test the circuit breaker in accordance with the instructions provided in Section 2, Part 5.

6.2 Insulating Surfaces

Using a clean, dry cloth, remove all dirt and moisture from the outside of the vacuum interrupters (Figure 8, 5) and from all insulating parts.

6.3 Mechanism

The entire breaker and operating mechanism should be inspected for loose hardware and worn or broken parts. All wiring should be checked for loose connections and damaged insulation. Inspect all bearings and contact surfaces for damage or excessive wear. Examine the shock absorber for evidence of leakage. Verify proper mechanism adjustments as specified in Section 5.



6.4 Lubrication

It should be noted that all bearings used in this series of vacuum circuit breakers are sealed and do not require lubrication.

The lubrication chart below provides the location of all lubrication points, the type of lubrication required and the two methods of lubrication. Method 1 is the periodic lubrication required after 3000 operations or one year, whichever occurs first. Method 2 is the lubrication procedure to be used whenever the breaker is overhauled or disassembled.

Severe operating conditions may warrant different lubrication intervals and procedures. Variations should be based on the experience of the operating company.

It is recommended that the breaker be manually operated several times after lubrication and observed for proper operation.

IMPORTANT: NEVER APPLY GREASE TO THE MACHINED SURFACE OF THE TRIP CLOSING CAM (FIGURE 5, 7) OR THE TRIP OPENING CAM (FIGURE 6, 10) OR THEIR RESPECTIVE CAM FOLLOWERS.

LUBRICATION CHART

LUBRICATION POINT	METHOD I Lubrication at Maintenance Period	METHOD II Lubrication at Overhaul
Gear teeth.	Wipe clean and apply lubricant.*	Disassemble, wipe clean, and apply lubricant.
Contact surfaces on lift arm (Fig. 5, 2), toggle cam (Figure. 6, 1), return spring connecting block (Figure. 10, 8) catch (Figure. 6, 2), etc.	Wipe clean and apply lubricant.	Disassemble, wipe clean, and apply lubricant.
Gear shaft (Fig. 4, 3) and drive shaft (Fig. 4, 10).	No lubrication required.	Disassemble, wipe clean, and apply lubricant to contact surfaces.
Ratchet arm (Fig. 4, 7).	No lubrication required.	Disassemble, wipe clean, and apply lubricant to bronze bushing and all contact surfaces.
Contact and pivot points of all linkages.	Wipe clean and apply lubricant.	Disassemble, wipe clean, and apply lubricant.
Drive spring assembly.	No lubrication required.	Do not disassemble. Wipe clean and apply lubricant to center shaft.
Motor eccentric (Fig. 4, 6) and eccentric roller.	Wipe clean and apply lubricant to slot in ratchet arm.	Disassemble, wipe clean, and apply lubricant.
All shafts, sleeves, spacers, and bushings.	No lubrication required.	Disassemble, wipe clean, and apply lubricant.
Silver plated primary disconnect (Fig. 7, 1) contacts, grounding contacts, and secondary contacts.	Wipe clean and apply a high quality conductive contact lubricant, such as G.E. #D50H47.	Wipe clean and apply a high quality conductive contact lubricant, such as G.E. #D50H47.

* It is recommended that a high grade, heavy duty lubricant, such as Texaco Multifac EP2, Chevron SRI Grease, or Lubriplate #630-2 be used.



VACUUM CIRCUIT BREAKER TYPE VAD-2
SERIES 2

6055

6.5 Electrical

Insure that all electrical connections are tight and clean. Using a high quality contact cleanser, clean the relay and auxiliary switch contacts.

6.6 Overhaul

After every 10,000 operations it is recommended that the breaker be given a thorough overhaul and that all components which have been excessively worn be replaced. Overhaul may require disassembly of the operating mechanism. For breaker lubrication, follow Method 2 in the lubrication chart. Check all bearings and replace if necessary. Check for proper adjustments and adjust if required.

7.0 RENEWAL PARTS

7.1 Minimum Requirements

Sufficient renewal parts should be maintained in stock to assure prompt replacement of worn, broken or damaged parts. A list of factory recommended renewal parts is provided below.

Because of the wide variation in operating uses and environments, the recommended renewal parts are presented only as a minimum requirement. Each operating company should develop its own renewal parts stock, based on operating experience, which will provide assurance of proper breaker condition.

7.2 Ordering Instructions

When ordering renewal parts:

- 1) Always specify the complete rating information and breaker serial number.
- 2) Specify part number, description of part, figure number (if provided) and the catalog from which this information is taken.
- 3) For electrical components, specify operating voltage.
- 4) Standard hardware components are not listed. These should be purchased locally.

Part No.	Description	Min. Qty.
1500D-2	Vacuum Interrupter Module	1
2021D	Trip Coil	1
2022D	Close Coil	1
1715D	Spring Charging Motor	1
2033D	Anti-Pump Relay	1
2013D	Motor Limit Switch	1
2029D	Auxiliary Switch	1
2032D	Motor Relay	1




VACUUM CIRCUIT BREAKER TYPE VAD-2 SERIES 2

INSTRUCTION
MANUAL 6055-3

CONTROL SCHEMATIC DIAGRAM

For AC and DC Application (Except for 250 Volt DC)



LEGEND



- 52 - VACUUM CIRCUIT BREAKER
- M - SPRING CHARGING MOTOR
- LS - SPRING CHARGING MOTOR LIMIT SWITCH
- TC - TRIP COIL (OPENING COIL)
- X - SPRING RELEASE COIL (CLOSING COIL)
- Y - ANTI-PUMP RELAY
- MR - MOTOR RELAY
- G - GREEN INDICATING LIGHT
- R - RED INDICATING LIGHT
- CS - CONTROL SWITCH
- ←← - INDICATES SECONDARY DISCONNECT POINT

NOTE:

- 1.) $\frac{52}{b}$ OPEN WHEN BREAKER IS CLOSED.
- 2.) $\frac{52}{a}$ OPEN WHEN BREAKER IS OPEN.
- 3.) DASHED LINES INDICATE USER SUPPLIED CIRCUITRY AND COMPONENTS.

SECONDARY DISCONNECT WIRING

(CIRCUIT BREAKER SIDE CONNECTION VIEW)



AUXILIARY CONTACTS

Figure 9A



VACUUM CIRCUIT BREAKER TYPE VAD-2
SERIES 2

6055




Figure 9B



VACUUM CIRCUIT BREAKER TYPE VAD-2 SERIES 2

INSTRUCTION
MANUAL 6055-3




Figure 10





Figure 11





SQUARE D COMPANY

330 Weakley Road, Smyrna, Tenn. 37167