



Basic Operator Panel BOP



1	2	3	4	5	6	7	8
External Interfaces					2400_BOP.vsd	Function diagram	- 2400 -
Basic Operator Panel (BOP)					16.01.2006 V2.1	MICROMASTER 440	