







D445



<1> For a SERVO drive object, the following applies: Can be used as fast measuring probe inputs.
 <2> Jumper open, electrical isolation for DI 0...3 and DI 4...7.

1	2	3	4	5	6	7	8
DO: CU_I					fp_1511_51_eng.vsd	Function diagram	
Overviews - D445 input/output terminals					12.06.06 V02.05.00	SINAMICS	
							- 1511 -