




1

2

3

4

5

6

7

8

DO: VECTOR

fp_6030_01_eng.vsd

Function diagram

Vector control - Speed setpoint, droop

18.04.07 V02.05.00

SINAMICS S

- 6030 -