




| 1                                                                                       | 2 | 3 | 4 | 5 | 6                  | 7                | 8        |
|-----------------------------------------------------------------------------------------|---|---|---|---|--------------------|------------------|----------|
| DO: TM41                                                                                |   |   |   |   | fp_9661_51_eng.vsd | Function diagram |          |
| Terminal Module 41 (TM41) - Digital inputs/outputs, bidirectional (DI/DO 0 ... DI/DO 1) |   |   |   |   | 10.03.06 V02.05.00 | SINAMICS         |          |
|                                                                                         |   |   |   |   |                    |                  | - 9661 - |