



1

2

3

4

5

6

7

8

DO: A_INFMV, B_INFMV
Auxiliaries - Braking module (r0108.26 = 1)

fp_9798_52_eng.vsd

function plan

- 9798 -

01.12.06 V02.05.00

SINAMICS GM/SM