




TYPE 30V CONTACTOR-1 POLE



DESCRIPTION	N/ U	PART NO.		R/S
		W.B.O.	W.O.B.O.	
COMPLETE ASSEMBLY	1	T415-G1	T415-G2	
1- ARMATURE ASSEMBLY	1	M564-G1	M564-G1	
2- MAIN CONTACT FINGER & SHUNT	1	K180-G5	K180-G5	*
3- COIL WASHER	1	X6D2	X6D2	
4- COIL (16 VOLTS)	1	X19H-G5	X19H-G5	*
(48 VOLTS)	1	X19G-G4	X19G-G4	*
(68 VOLTS)	1	X19G-G5	X19G-G5	*
(120 VOLTS)	1	X19G-G2	X19G-G2	*
(120 VOLTS)	1	X19H-G2	X19H-G2	*
(240 VOLTS)	1	X19G-G1	X19G-G1	*
(240 VOLTS)	1	X19H-G1	X19H-G1	*
(300 VOLTS)	1	X19G-G3	X19G-G3	*
(300 VOLTS)	1	X19H-G3	X19H-G3	*
5- PIVOT PIN	1	X12R1	X12R1	
6- MAIN STATIONARY CONTACT & HOLDER	1	P519-G3	P519-G6	
A- MAIN STATIONARY CONTACT HOLDER	1	P441-5	P441-3	
B- MAIN STATIONARY CONTACT	1	K179-1	K179-1	*
C- CONNECTOR ARC HORN	1	P441-10	—	*
D- ARC SHIELD	2	P441-13	—	*
E- BLOWOUT COIL	1	X19J-G1	—	*
7- MAKE INTERLOCK CONTACT SUPPORT	2	T415-G5	T415-G5	
8- CONTACT & HOLDER (STATIONARY)	4	M1230-G3	M1230-G3	*
9- CONTACT & SHUNT (MOVING)	4	M1230-G5	M1230-G5	*
10- BREAK INTERLOCK CONTACT SUPPORT	2	T415-G6	T415-G6	
11- STOP PLATE	1	P5-3	P5-3	
12- STATIONARY FRAME	1	K1-G2	K1-G2	